

HD SK Custom Flow Control Valve for Bathroom and Kitchen Sinks

Installation Instructions

The Flow Control Valve for Bathroom and Kitchen Sinks with a National Sanitation Foundation (NSF) Certified Washer is easily installed underneath your sink at the angle stop.

View installation video @ www.hdconservation.com/products

1. Go underneath the sink and locate the hot and cold angle stops and turn to the off position.
2. Remove the flex line at the angle stop with an adjustable wrench.
3. Clean debris out of supply line.
4. Check the FCV washer to ensure it is fully seated in the FCV.
5. Wrap plumbing tape in a clockwise motion on the angle stop if necessary
6. Attach the Custom Flow Control Valve to the hot and cold water side of the angle stops and tighten. Make sure the washer is seated against the angle stop. Do not continue if the part is not seated properly against the angle stop.
7. Reattach flex line to the Flow Control Valve and tighten. Flex line can be tightened down harder than the angle stop.
8. Ensure the Flow Control Valve is installed tightly and securely. Be sure not to over tighten.
9. Turn on the water supply at the angle stop and inspect for leaks. Leaks can be caused by over tightening or under tightening.
10. Your faucet is now ready for use.

